

C0000 – C0999 CODES STANDARDS CHASSIS : FREINAGE et CONTRIOLE TRACTION.

C0000	ISO/SAE Reserved
C0001	TCS Control Channel "A" Valve 1 (Subfault)
C0002	TCS Control Channel "A" Valve 2 (Subfault)
C0003	TCS Control Channel "B" Valve 1 (Subfault)
C0004	TCS Control Channel "B" Valve 2 (Subfault)
C0005	ISO/SAE Reserved
C0006	ISO/SAE Reserved
C0007	ISO/SAE Reserved
C0008	ISO/SAE Reserved
C0009	ISO/SAE Reserved
C000A	ISO/SAE Reserved
C000B	ISO/SAE Reserved
C000C	ISO/SAE Reserved
C000D	ISO/SAE Reserved
C000E	ISO/SAE Reserved
C000F	ISO/SAE Reserved
C0010	Left Front Inlet Control (Subfault)
C0011	Left Front Outlet Control (Subfault)
C0012	Left Front Hydraulic Release Too Long (Subfault)
C0013	ISO/SAE Reserved
C0014	Right Front Inlet Control (Subfault)
C0015	Right Front Outlet Control (Subfault)
C0016	Right Front Hydraulic Release Too Long (Subfault)
C0017	ISO/SAE Reserved
C0018	Left Rear Inlet Control (Subfault)
C0019	Left Rear Outlet Control (Subfault)
C001A	Left Rear Hydraulic Release Too Long (Subfault)
C001B	ISO/SAE Reserved
C001C	Right Rear Inlet Control (Subfault)
C001D	Right Rear Outlet Control (Subfault)

C001E	Right Rear Hydraulic Release Too Long (Subfault)
C001F	ISO/SAE Reserved
C0020	ABS Pump Motor Control (Subfault)
C0021	Brake Booster Performance (Subfault)
C0022	Brake Booster Solenoid (Subfault)
C0023	Stop Lamp Control (Subfault)
C0024	ISO/SAE Reserved
C0025	ISO/SAE Reserved
C0026	ISO/SAE Reserved
C0027	ISO/SAE Reserved
C0028	ISO/SAE Reserved
C0029	ISO/SAE Reserved
C002A	ISO/SAE Reserved
C002B	ISO/SAE Reserved
C002C	ISO/SAE Reserved
C002D	ISO/SAE Reserved
C002E	ISO/SAE Reserved
C002F	ISO/SAE Reserved
C0030	Left Front Tone Wheel (Subfault)
C0031	Left Front Wheel Speed Sensor (Subfault)
C0032	Left Front Wheel Speed Sensor Supply (Subfault)
C0033	Right Front Tone Wheel (Subfault)
C0034	Right Front Wheel Speed Sensor (Subfault)
C0035	Right Front Wheel Speed Sensor Supply (Subfault)
C0036	Left Rear Tone Wheel (Subfault)
C0037	Left Rear Wheel Speed Sensor (Subfault)
C0038	Left Rear Wheel Speed Sensor Supply (Subfault)
C0039	Right Rear Tone Wheel (Subfault)
C003A	Right Rear Wheel Speed Sensor (Subfault)
C003B	Right Rear Wheel Speed Sensor Supply (Subfault)
C003C	Rear Tone Wheel (Subfault)
C003D	Rear Wheel Speed Sensor (Subfault)

C003E	Rear Wheel Speed Sensor Supply (Subfault)
C003F	ISO/SAE Reserved
C0040	Brake Pedal Switch "A" (Subfault)
C0041	Brake Pedal Switch "B" (Subfault)
C0042	Brake Pedal Position Sensor "Circuit A" (Subfault)
C0043	Brake Pedal Position Sensor "Circuit B" (Subfault)
C0044	Brake Pressure Sensor "A" (Subfault)
C0045	Brake Pressure Sensor "B" (Subfault)
C0046	Brake Pressure Sensor "A"/"B" (Subfault)
C0047	Brake Booster Pressure Sensor (Subfault)
C0048	Brake Booster Travel Sensor (Subfault)
C0049	Brake Fluid (Subfault)
C004A	Brake Lining Wear Sensor (Subfault)
C004B	ISO/SAE Reserved
C004C	ISO/SAE Reserved
C004D	ISO/SAE Reserved
C004E	ISO/SAE Reserved
C004F	ISO/SAE Reserved
C0050	ISO/SAE Reserved
C0051	Steering Wheel Position Sensor (Subfault)
C0052	Steering Wheel Position Sensor "Signal A" (Subfault)
C0053	Steering Wheel Position Sensor "Signal B" (Subfault)
C0054	Steering Wheel Position Sensor "Signal C" (Subfault)
C0055	Steering Wheel Position Sensor "Signal D" (Subfault)
C0056	ISO/SAE Reserved
C0057	ISO/SAE Reserved
C0058	ISO/SAE Reserved
C0059	ISO/SAE Reserved
C005A	ISO/SAE Reserved
C005B	ISO/SAE Reserved
C005C	ISO/SAE Reserved
C005D	ISO/SAE Reserved

C005E	ISO/SAE Reserved
C005F	ISO/SAE Reserved
C0060	ISO/SAE Reserved
C0061	Lateral Acceleration Sensor (Subfault)
C0062	Longitudinal Acceleration Sensor (Subfault)
C0063	Yaw Rate Sensor (Subfault)
C0064	Roll Rate Sensor
C0065	ISO/SAE Reserved
C0066	ISO/SAE Reserved
C0067	ISO/SAE Reserved
C0068	ISO/SAE Reserved
C0069	Yaw Rate/Longitude Sensors (Subfault)
C006A	Multi-axis Acceleration Sensor (Subfault)
C006B	Stability System Active Too Long (Subfault)
C006C	Stability System
C006D	ISO/SAE Reserved
C006E	ISO/SAE Reserved
C006F	ISO/SAE Reserved
C0070	ISO/SAE Reserved
C0071	2/4 Wheel Drive Status Input (Subfault)
C0072	Brake Temperature Too High (Subfault)
C0073	Delivered Driving Torque (Subfault)
C0074	Requested Driving Torque (Subfault)
C0075	Extended Brake Pedal Travel, output to PCM (Subfault)
C0076	PWM for Traction Control (Subfault)
C0077	Low Tire Pressure (Subfault)
C0078	Tire Diameter (Subfault)
C0079	Variable Effort Steering (Subfault)
C007A	ISO/SAE Reserved
C007B	ISO/SAE Reserved
C007C	ISO/SAE Reserved
C007D	ISO/SAE Reserved

C007E	ISO/SAE Reserved
C007F	ISO/SAE Reserved
C0080	ISO/SAE Reserved
C0081	ABS Malfunction Indicator (Subfault)
C0082	Brake System Malfunction Indicator (Subfault)
C0083	Tire Pressure Monitor Malfunction Indicator (Subfault)
C0084	Traction Active Indicator (Subfault)
C0085	Traction Disable Indicator (Subfault)
C0086	Vehicle Dynamics Indicator (Subfault)
C0087	ISO/SAE Reserved
C0088	ISO/SAE Reserved
C0089	TCS Disable Switch (Subfault)
C008A	TCS Mode Control (Subfault)
C008B	ISO/SAE Reserved
C0100	Rear ABS (both wheels) solenoid/motor #1 circuit malfunction
C0300	Rear Propshaft Speed Sensor